


PARTS CATALOG

TAKE-OUT ROBOT

- NEXIA-1000SW (M100ULA000NKS0)

Ver. 1.1

NEXIA-1000SW (M100ULA000NKS0)




Contents

A. Traverse unit (M080UMA100NKS0)	4
B. Kick unit (M100ULA200N000)	6
C. Main Arm unit (M100ULA400NKA0)	8
D. Rotation unit (M060HFA5000000)	10
E. Controller unit (M130VLS9300K00)	12
F. Swivel unit-Option (M080JJA7000000)	14

- 이책의 내용에 관해서는 향후 예고 없이 변경될 수 있습니다.
- 이 책에 기재되어 있는 데이터는, 이 기계에 관계된 참고 데이터로서 기재된 것이며 법적 책임을 가지고 있는 것은 아닙니다.
- 고객측의 개조, 분해, 오용 및 설치 환경 부족 등, 당사가 관여할 수 없는 상황에서 발생하는 손실에 관한 책임은 지지 않습니다.
- 당사에서는 이 장치의 운용을 이유로 하는 손실, 잘못된 이익 등의 청구에 관해서는 어떠한 책임도 질 수 없다는 것을 양해해 주십시오.
- 이 책의 모든 저작권은 한양로보틱스(주)에 귀속됩니다. 이 책 내용의 전체 또는 일부를 당사의 허가 없이 복제, 복사, 전재(全載)하는 일은 저작권 및 출판사의 권리를 침해하는 일입니다.

A. Traverse unit (M080UMA100NKS0)




A. Traverse unit (M080UMA100NKS0)

No.	PARTS No.	PARTS NAME	Q'TY	REMARKS
A-1	X080UMA1001PW0	Body	1	
A-2	PLMRSAH303480L	LM rail	2	
A-3	PLMBSAH30AL888	LM block	6	
A-4	M080ULA1003ZZ0	LM base	1	
A-5	M080ULA1007ZZ0	Plate	1	
A-6	PRESSFS9DPB088	Reducer	2	
A-7	PMTBEMJ08APB22	Servo motor	2	
A-8	M060KQE1008ZZ0	Helical gear	1	
A-9	PPLMMA24428888	Power lock	2	
A-10	M080ULA2006ZZ0	Plate	1	
A-11	M080ULA2024ZZ0	Plate	1	
A-12	M080JPA1008ZZ0	Helical gear	1	
A-13	PSSRHYP18S5NAF	Sensor	1	
A-14	M015MAB1017MC0	Bracket	1	
A-15	PSSMRS52SH8888	Magnet sensor	1	
A-16	M080ULA2020ZZ0	Pin	6	
A-17	M080ULA2008ZZ0	Cableveyor bracket	1	
A-18	PCVH4502B09588	Cableveyor link	23	
A-19	PCVE4502300088	Cableveyor end bracket	1	
A-20	M250ULA2018MC0	Bracket	1	
A-21	PSSMRS52SHC888	Magnet	2	
A-22	PCVH6252B12588	Cableveyor link	34	
A-23	PCVE6252300088	Cableveyor end bracket	1	
A-24	M080UMA1010ZZ0	Cableveyor plate	1	
A-25	M040HFA1018MC0	Bracket	1	
A-26	M080UMA1050ZZ0	Helical rack	1	
A-27	M040HFA1007ZZ0	Bracket	1	
A-28	M080ULA1011ZZ0	Cover	2	
A-29	PAXSTAW4000ASY	Filter regulator	1	
A-30	MXAKAAB1000000	Counter	1	
A-31	MN20TEA1021PW0	Plate	1	
A-32	M040HFA1021PW0	Spacer	1	

[illegible]


B. Kick unit (M100ULA200N000)



B. Kick unit (M100ULA200N000)

[illegible][illegible]

C. Main_Arm unit (M100ULA400NKA0)




C. Main_Arm unit (M100ULA400NKA0)

No.	PARTS No.	PARTS NAME	Q'TY	REMARKS
C-1	M100ULA4006MC0	File	1	
C-2	PLMRSAH201230L	LM rail	2	
C-3	PLMBSAH20AN888	LM block	8	
C-4	M060HFA4048ZZ0	Gripper block	1	
C-5	M100ULA4020MC0	Helical rack	1	
C-6	PSSRHYP18S5NAF	Sensor	1	
C-7	M080ULA4056ZZ0	Block	2	
C-8	M060HFA4020ZZ0	Bearing block	1	
C-9	M060HFA4019ZZ0	Bearing block	1	
C-10	M060HFA4036ZZ0	Collar	4	
C-11	M060HFA4025ZZ0	Roller	2	
C-12	PBRA6203ZZ8888	Bearing	4	
C-13	PRGH040H888888	Snap ring	2	
C-14	M060HFA4021ZZ0	Shaft	1	
C-15	M060HFA4024ZZ0	Shaft	1	
C-16	M080ULA4011ZZ0	Pulley block	1	
C-17	M060HFA4023ZZ0	Pulley block	1	
C-18	M060HFA4065ZZ0	Bracket	2	
C-19	M250ULA4040ZZ0	Plate	1	
C-20	M060HFA4045ZZ0	Cover	1	
C-21	PBLTU8M2588888	Timing belt	2752	
C-22	M080ULA4014MC0	Gripper	1	
C-23	M080ULA4017ZZ0	Gripper block	1	
C-24	M130VLS4001ZZ0	Plate-C	1	
C-25	M080ULA4012ZZ0	Belt gripper	2	
C-26	M080ULA4046MC0	Gripper	2	
C-27	M130VLS4017ZZ0	Plate	1	
C-28	PRESAB15102KG20	Reducer	1	
C-29	PMTBEMJ20APA24	Servo motor	1	
C-30	M130VLS4018ZZ0	Helical gear	1	
C-31	PPLMDR132A3260	Power lock	1	
C-32	M130VLS4002ZZ0	Plate	1	

[illegible]

D. Rotation unit (M060HFA5000000)




D. Rotation unit (M060HFA5000000)

[illegible][illegible]


E. Controller unit (M130VLS9300K00)

12



E. Controller unit (M130VLS9300K00)

No.	PARTS No.	PARTS NAME	Q'TY	REMARKS	No.	PARTS No.	PARTS NAME	Q'TY	REMARKS
E-1	M080JPE9002ZZ0	Body	1		E-33	PFTEWYFT20T1A8	Noise filter	1	
E-2	M020HFA9004ZZ0	Controller bracket	2		E-34	PNSCABS33B1088	Circuit breake	1	
E-3	PMXK25M6888888	Antivibration gels	4		E-35	ES55TW4610060E	Buzzer	1	
E-4	M080JPE9003ZZ0	Plate	1		E-36	M020KKA9032ZZ0	Cover	1	
E-5	M200ULS9020MC0	Terminal chnnel	1		E-37	PEXJTBOXJB001A	Ketop handheld terminals	1	
E-6	PBDKBCPUCP232Z	CPU set(Central processor module)	1		E-38	PEXELEBAR14588	Earth Bar	1	
E-7	PBDIOMODDM276A	I/O modules	4		E-39	M020KKA9023MC0	Plate	1	
E-8	M020KKA9009ZZ0	Controller bracket	1		E-40	PBDCLEDKEBA888	Board	1	
E-9	M030SBA9026MC0	Duct-30	1		E-41	PEXSFM30588888	Support	4	
E-10	PMTXPNE08A8888	Servo drive	2		E-42	M130JFG9012ZZ0	Cover	1	
E-11	PMTXPNE20A8888	Servo drive	1		E-43	M080JPE9013ZZ0	Cover	1	
E-12	M020KFE9005ZZ0	Controller bracket	1		E-44	M080JPE9014ZZ0	Cover	1	
E-13	M020KFE9006ZZ0	Controller bracket	1		E-45	PMXBY117888888	Hook	2	
E-14	M020HFA9007ZZ0	Controller bracket	2		E-46	PMXBYHS1560888	Hinge	2	
E-15	PEXRS300W25K88	Regenerative resistor	2						
E-16	PEXFSJ1238HA28	Fan	2						
E-17	PEXFS105105888	Fan cover	2						
E-18	PEXFSJ12COVER8	Fan cover	2						
E-19	PMXCAPRUBPAK30	Cap	2						
E-20	M080JPE9010ZZ1	Plate	1						
E-21	MN20KFA9029MC0	Duct-30	1						
E-22	M020KKA9021MC0	Terminal chnnel	1						
E-23	PSMPPRO2402410	Power supply	1						
E-24	M200ULS9021MC0	Terminal chnnel	1						
E-25	PRLKLY28888888	Relay socket	1						
E-26	PRLALY2N1DC248	Relay	1						
E-27	PTLD0600015288	Terminal	5						
E-28	PTLD0600015888	Separator	1						
E-29	M020KKA9025MC0	Duct-30	1						
E-30	PBDINTKEBAV102	Board	1						
E-31	PEXSFM31005888	Support	7						
E-32	PNSEGMC2288888	Contactor	1						



F. Swivel unit-Option (M080JJA7000000)

[illegible][illegible]

본사 (Head Office & Factory)

인천광역시 서구 보도진로 41번길 9 (가좌동) (우:404-811)
TEL : 032-582-5040, 032-582-5046
FAX : 032-584-7040
WWW.HYROBOT.COM

HANYANG ROBOTICS CO., LTD
9, Bodojin-Ro 41 Beon-Gil, Seo-Gu, Incheon, Korea (404-811)
TEL : +82-32-582-5040, +82-32-582-5046
FAX : +82-32-584-7040
WWW.HYROBOT.COM

HYROBOTICS CORP.
5988 Mid Rivers Mall Dr. Saint Charles. MO 63304. USA
TEL : 1-636-578-6059
FAX : 1-866-232-5594
WWW.HYROBOT.COM

